

3 Step Installation:

- 1 Slide Lock Around Wheel.
- 2 Crank Lock Tight To Wheel.
- 3 Crank Disc Arm Tight Against Lug Nuts & Lock.

